



## **IMPORTANT NOTE WHEN ASSEMBLING THE RX BRIDGES**

**When attaching the lid to the case, small black self tapping screws are used. Sometimes these small screws are a tight fit into the pillar holes.**

**A worthwhile hint is to screw these self tappers into the holes without the lid first. This cuts a thread into the pillar hole.**

**The reason for this is that if the screw is too tight when entering the hole, the screw either jams and breaks or the head cross thread is damaged making it quite difficult to remove and retry.**

**Without the lid in place first, should the screw jam, it can be removed by gripping the body of the screw and damaged head with a pair of pliers and removing it. This cannot be done easily if the lid is in place.**

**You can understand that once the screw is jammed and the head damaged with the lid in place, you virtually have to damage the lid to rectify the situation.**

**Once you have driven a screw into each pillar and then removed it, the chances of a jam are much less when you go to attach the lid.**

**This is a very worthwhile extra step and can alleviate a lot of frustration later.**

**Also, in some kits the screw head may be smaller than the common "2" size. Try a selected screw driver in the cross head for correct size before starting. Most kits now use a smaller screw driver head size.**

**A good fit also reduces the risk of damage.**

**Thank you,**

**Lou, VK3AQZ**